

<b>Audi</b>	Audi 1.8L Turbo	1050.60.14.14.4	ID1050x, for Audi/VW 1.8t, 14mm (purple) top set of 4
	Audi 2.0L Turbo	1050.60.14.14.4	ID1050x, for Audi/VW 2.0t, 14mm (purple) top set of 4
	Audi VR6 (12 valve)	1050.60.14.14.6	ID1050x, for Audi/VW VR6 models (12 valve), 14mm (purple) adaptors. Set of 6
	Audi VR6 (24 valve)	N/A	34mm length will not fit the 24 valve head, the bore in the head is too deep
<b>BMW</b>	E30 M3 88-91	1050.60.14.14.4	ID1050x, for BMW E30 M3, 14 mm (purple) adaptors, set of 4.
	E36 M3 96-99	1050.60.14.14.6	ID1050x, for BMW E36 M3, 14mm (purple) adaptors, set of 6.
	E46 M3 01-06	1050.48.14.14.6	ID1050x, for BMW E46 M3, 14mm (grey) adaptor top, set of 6.
	E90 / E92 / E93 M3 07+	1050.48.14.14.8	ID1050x, for BMW E90 / E92 / E93 M3 2007+, 14mm (grey) adaptor top. Set of 8.
	M Coupe / M Roadster 98	1050.60.14.14.6	ID1050x, for BMW M Coupe & M Roadster, 14mm (purple) adaptors, set of 6.
	540i / 740i	1050.60.14.14.8	ID1050x, for BMW 5/7 Series, 14mm (purple) adaptors, set of 8.
	328 96-98	1050.60.14.14.6	ID1050x, for BMW E36, 14mm (purple) adaptors, set of 6.
<b>Buick</b>	Turbo Regal	1050.60.14.14.6	ID1050x, for Turbo Regal, 14mm (purple) adaptors, set of 6
	Grand National	1050.60.14.14.6	ID1050x, for Grand National, 14mm (purple) adaptors, set of 6
<b>Cadillac</b>	CTS-V 09+ (LSA)	1050.34.14.15.8	ID1050x, for CTS-V 2009+ / LSA 6.2L applications. Direct replacement (no adapter top). Orange lower o-ring, set of 8.
<b>Chevrolet</b>	LS3/LS7/L76/L92/L99	1050.34.14.15.8	ID1050x, for GM LS3/LS7/L76/L92/L99, standard (no adaptor), Orange lower o-ring, set of 8
	LS2	1050.48.14.15.8	ID1050x, for GM LS2, 14mm (grey) adaptor top, set of 8. Orange lower o-ring.
	LS1/LS6	1050.60.14.14.8	ID1050x, for GM LS1/LS6, 14mm (purple) adaptors, set of 8
	Camaro 93-96 (LT1)	1050.60.14.14.8	ID1050x, for GM LT1, 14mm (purple) adaptors, set of 8
	Camaro 98-01 (LS1)	1050.60.14.14.8	ID1050x, for GM LS1/LS6, 14mm (purple) adaptors, set of 8
	Camaro 10+ (LS3)	1050.34.14.15.8	ID1050x, for GM LS3, standard (no adaptor), Orange lower o-ring, set of 8.
	Camaro ZL1 (LSA)	1050.34.14.15.8	ID1050x, for 2012+ Camaro ZL1 / GM LSA, standard (no adapter), Orange lower o-ring, set of 8.
	C5 Corvette (incl Z06)	1050.60.14.14.8	ID1050x, for GM LS1/LS6, 14mm (purple) adaptors, set of 8
	C6 Corvette	1050.34.14.15.8	ID1050x, for GM LS3/LS7/L76/L92/L99, standard (no adaptor), Orange lower o-ring, set of 8
	C6 Z06 (LS7)	1050.34.14.15.8	ID1050x, for GM LS3/LS7/L76/L92/L99, standard (no adaptor), Orange lower o-ring, set of 8
	C6 ZR1 (LS9)	1050.34.14.15.8	ID1050x, for GM LS9, Direct replacement (no adaptor top), Orange lower o-ring, set of 8.
Cobalt SS (super)	1050.60.14.14B.4	ID1050x, for 2.0L/2.2L supercharged engines. 60mm length, 14 mm (grey) adaptor top AND (silver) BOTTOM adaptor. Set of 4.	
<b>Chrysler</b>	Neon SRT-4	1050.48.14.14.4	ID1050x, for Dodge SRT-4 / 2.4L turbocharged engines. Direct fit, plug & play. 14mm (grey) adaptors. Set of 4.
<b>Dodge</b>	Caliber SRT-4	1050.48.14.14.4	ID1050x, for Dodge SRT-4 / 2.4L turbocharged engines. Direct fit, plug & play. 14mm (grey) adaptors. Set of 4.
	300C SRT-8	1050.48.14.14B.8	ID1050x, for Dodge SRT-8 / 6.4L engines. 14mm (black) BOTTOM adaptor. Set of 8.
	Challenger SRT-8	1050.48.14.14B.8	ID1050x, for Dodge SRT-8 / 6.4L engines. 14mm (black) BOTTOM adaptor. Set of 8.
	Magnum SRT-8	1050.48.14.14B.8	ID1050x, for Dodge SRT-8 / 6.4L engines. 14mm (black) BOTTOM adaptor. Set of 8.
	Hellcat	1050.48.14.14.8	ID1050x, for Dodge Hellcat / 6.2L supercharged engines. Direct fit, plug & play. 14mm (grey) adaptors. Set of 8.
	Viper 03-07	1050.60.14.14.10	ID1050x, for Dodge SRT-10 / 8.3L engines. 14mm (purple) adaptors. Vehicle must be converted to top-feed injector fitment. Set of 10.
	Ram SRT-10 04-06	1050.60.14.14.10	ID1050x, for Dodge SRT-10 / 8.3L engines. 14mm (purple) adaptors. Vehicle must be converted to top-feed injector fitment. Set of 10.
	Viper 08+	1050.48.14.14B.10	ID1050x, for Dodge SRT-10 / 8.3L & 8.4L engines. 14mm (black) bottom adaptors. Set of 10.
<b>Ford</b>	Focus ZX3	1050.60.14.14.4	ID1050x, for Ford Focus ZX3 applications, 14mm (purple) adaptors. Set of 4.
	Focus SVT	1050.60.14.14.4	ID1050x, for Ford Focus SVT applications, 14mm (purple) adaptors. Set of 4.
	Focus RS	1050.60.14.14.4	ID1050x, for Ford RS MKI applications, 14 mm (purple) adaptors. Set of 4.
	Focus RS MK II-IV	1050.60.14.14.5	ID1050x, for Ford RS MKII-IV applications, 14 mm (purple) adaptors. Set of 5.
	SVT Lightning	1050.60.14.14.8	ID1050x, for Ford Lightning truck / 5.4L supercharged applications. 14mm (purple) adaptors. Set of 8.
	F150 Harley Davidson	1050.60.14.14.8	ID1050x, for Ford Lightning truck / 5.4L supercharged applications. 14mm (purple) adaptors. Set of 8.

	Mustang SVO	1050.60.14.14.4	ID1050x, for SVO, T-bird Super Coupe, Merkur XR4Ti, Turbo Cougar / 2.3L turbo applications. 14mm (purple) adaptors. Set of 4.
	Mustang GT 88-96	1050.60.14.14.8	ID1050x, for Mustang GT 5.0L applications. 14mm (purple) adaptors. Set of 8.
	Mustang GT 97-04	1050.60.14.14.8	ID1050x, for Mustang GT 4.6L applications. 14mm (purple) adaptors. Set of 8.
	Mustang GT 05-10	1050.60.14.14.8	ID1050x, for 05-10 Ford Mustang GT 4.6L applications. 14mm (purple) adaptors. Direct plug-in. Set of 8.
	Mustang GT 2011+	1050.60.14.14B.8	ID1050x, for 2011+ Ford Mustang GT 5.0L Coyote applications. 14 mm (grey) adaptor top AND (silver) BOTTOM adaptor. Direct plug-in. Set of 8.
	Mustang Cobra 99-04	1050.60.14.14.8	ID1050x, for 99-04 Ford Cobra 4.6L Supercharged. 14mm (purple) adaptors. Set of 8.
	Mustang GT500	1050.48.14.14.8	ID1050x, for 06+ Ford Mustang GT500. 14mm (grey) adaptors. Direct fitment.
	FG Falcon GT and GS 5.0	1050.60.14.14B.8-PU	ID1050x, for Ford FG Falcon GT and GS, 5 liter, 2010 +. 14 mm (grey) adaptor top AND (silver) BOTTOM adaptor. Set of 8
			Includes potted PNP wiring adaptors
	Falcon XR6 Turbo (FG)	1050.48.14.14B.6	ID1050x, for FG Ford Falcon XR6 turbo. 14mm (black) BOTTOM adaptor. Set of 6.
	Falcon XR6 Turbo (BA and	1050.60.14.14B.6	ID1050x, for BA/BF Ford Falcon XR6 turbo. 14 mm (grey) adaptor top AND (silver) BOTTOM adaptor. Set of 6.
	SVT Raptor 2011+	1050.60.14.14.8	ID1050x, for 2011+ SVT Raptor 6.2L applications. 14mm (purple) adaptors. Set of 8.
<b>Holden</b>	Commodore VT (V6)	1050.60.14.14.6	ID1050x, for Commodore VT / V6 application. 14mm (purple) adaptors. Set of 6.
	Commodore VTII (LS1)	1050.60.14.14.8	ID1050x, for Commodore VTII. 14mm (purple) adaptors. Set of 8.
	Commodore VX (LS1)	1050.60.14.14.8	ID1050x, for Commodore VX. 14mm (purple) adaptor tops. Set of 8.
	Commodore VXII (V6)	1050.60.14.14.6	ID1050x, for Commodore VXII 3.8L S/C V6. 14mm (purple) adaptor top. Set of 6.
	Commodore VY (LS1)	1050.60.14.14.8	ID1050x, for Commodore VY / LS1. 14mm (purple) adaptor top. Set of 8.
	Commodore VS/VY (SCV6	1050.60.14.14.6	ID1050x, for Commodore VS/VY 3.8L S/C V6. 14mm (purple) adaptor top. Set of 6.
	Commodore VZ (LS2)	1050.48.14.15.8	ID1050x, for Commodore VZ / LS2 application. 14mm (grey) adaptor top, set of 8. Orange lower o-ring.
	Commodore W427	1050.34.14.15.8	ID1050x, for Commodore W427 / LS7. Standard (no adaptor), Orange lower o-ring, set of 8
	Commodore E-HSV	1050.34.14.15.8	ID1050x, for Commodore E Series HSV / LS3 applications. Standard (no adaptor), Orange lower o-ring, set of 8
	Monaro (LS1)	1050.60.14.14.8	ID1050x, for Monaro / LS1 applications. 14mm (purple) adaptor tops. Set of 8.
	Monaro (LS2)	1050.48.14.15.8	ID1050x, for Monaro / LS2 applications. Orange lower o-ring. 14mm (grey) adaptor top, set of 8.
<b>Honda</b>	Accord 92-95	1050.60.11.14.4	ID1050x, for 92-95 Accord / F & H Series. 11mm (blue) adaptors. Set of 4.
<b>Acura</b>	Accord 96-02	1050.60.11.14.4	ID1050x, for 96-02 Accord / F & H series. 11mm (blue) adaptors. Set of 4.
	Accord 03-07	1050.48.11.F20.6	ID1050x, for 03-07 Accord / J-series V6. 11mm (red) adaptors. S2K lower. Set of 6.
	Civic 88-95	1050.60.11.14.4	ID1050x, for 88-95 Civic / B, D, H, F Series. 11mm (blue) adaptors. Set of 4.
	Civic 96-00	1050.60.11.14.4	ID1050x, for 96-00 Civic / B, D, H, F Series. 11mm (blue) adaptors. Set of 4.
	Civic 02-05 Si	1050.48.14.14.4	ID1050x, for 02-05 Civic Si / K-series. 14mm (grey) adaptor top. Set of 4.
	Civic 06-11	1050.48.14.14.4	ID1050x, for 06-11 Civic Si / K-series. 14mm (grey) adaptor top. Set of 4.
	Civic Si 12-15	1050.07.21.48.14.4	ID1050x, for 12-15 Civic Si. 14mm (grey) adapter top. Denso lower OVER the o-ring retainer. Do not remove retainer. Set of 4.
	Odyssey 02-04	1050.48.11.F20.6	ID1050x, for 02-04 Odyssey / J-series V6. 11mm (red) adaptors. S2K lower. Set of 6.
	Prelude 92-96	1050.60.11.14.4	ID1050x, for 92-96 Prelude / F & H Series. 11mm (blue) adaptors. Set of 4.
	Prelude 97-01	1050.60.11.14.4	ID1050x, for 97-01 Prelude / F & H Series. 11mm (blue) adaptors. Set of 4.
	S2000 00-05	1050.48.11.F20.4	ID1050x, for 00-05 S2000 / F series. 11mm (red) adaptors. S2K lower. Set of 4.
	S2000 06-09	1050.48.14.14.4	ID1050x, for 06+ S2000 / F series. 14mm top. 14mm (grey) adaptor top. Set of 4.
	CL 01-03	1050.48.11.F20.6	ID1050x, for 01-03 CL / J-series V6. 11mm (red) adaptors. S2K lower. Set of 6.
	Integra 90-95	1050.60.11.14.4	ID1050x, for 90-95 Integra / B & H Series, 11mm (blue) adaptors. Set of 4.
	Integra 96-01	1050.60.11.14.4	ID1050x, for 96-01 Integra / B & H Series, 11mm (blue) adaptors. Set of 4.
	NSX 91-96	1050.60.11.14-O.6	ID1050x, for 91-96 NSX / C Series, 11mm (blue) adaptors. 14mm bottom o-ring, machine o-ring retainer to 11mm. Set of 6.
	NSX 97-05	1050.60.11.14-O.6	ID1050x, for 97-05 NSX / C Series, 11mm (blue) adaptors. 14mm bottom o-ring, machine o-ring retainer to 11mm. Set of 6.
	RSX 02-09	1050.48.14.14.4	ID1050x, for 02-09 RSX / K-series. 14mm (grey) adaptor top. Set of 4.
	TL 01-03	1050.48.11.F20.6	ID1050x, for 01-03 TL / J-series V6. 11mm (red) adaptors. S2K lower. Set of 6.
	TSX 04-10	1050.48.14.14.4	ID1050x, for 04-10 TSX / K-series. 14mm (grey) adaptor top. Set of 4.

<b>Hyundai</b>	Genesis 2.0t 09-12	1050.48.14.R35.4	ID1050x, for 2009-12 Genesis 2.0 Turbo. 14mm (grey) adaptor. GTR lower spacer. Set of 4.
	Genesis 2.0t 13-14	1050.60.14.14.4	ID1050x, for 2013-14 Genesis 2.0 Turbo. 14mm (purple) adaptor. Set of 4.
	Genesis V6 09+	1050.34.14.14.6	ID1050x, for 2009+ Genesis V6. Direct replacement (no adapter top). 14mm lower o-ring, set of 6.
<b>Infiniti</b>	G35	1050.48.14.14.6	ID1050x, for G35 / VQ35 applications. 14mm (grey) adaptor top. Set of 6.
	G37	1050.48.14.R35.6	ID1050x, for G37 / VQ37 applications. 14mm (grey) adaptor top. GTR lower spacer. Set of 6.
	G20 91-96 (11mm)	1050.60.11.14.4	ID1050x, for G20 / FWD SR20 applications. Must be converted to top-feed. 11mm (blue) adaptor. Set of 4.
	G20 91-96 (14mm)	1050.60.14.14.4	ID1050x, for G20 / FWD SR20 applications. Must be converted to top-feed. 14mm (purple) adaptor. Set of 4.
	G20 99-02 (11mm)	1050.60.11.14.4	ID1050x, for G20 / FWD SR20 applications. Must be converted to top-feed. 11mm (blue) adaptor. Set of 4.
	G20 99-02 (14mm)	1050.60.14.14.4	ID1050x, for G20 / FWD SR20 applications. Must be converted to top-feed. 14mm (purple) adaptor. Set of 4.
<b>Lamborghini</b>	Gallardo 04+	1050.48.14.14.10	ID1050x, for 04+ Gallardo / V10 applications. 14mm (grey) adaptor top. Set of 10.
<b>Lexus</b>	GS300	1050.60.11.D.6	ID1050x, for GS300 / 2JZ-GE (non turbo) applications. 11mm (blue) adaptor tops. Denso lower cushions. Set of 6.
	IS300	1050.60.11.D.6	ID1050x, for IS300 / 2JZ-GE (non-turbo) applications. 11mm (blue) adaptor tops. Denso lower cushions. Set of 6.
	SC300	1050.60.11.D.6	ID1050x, for SC300 / 2JZ-GE (non-turbo) applications. 11mm (blue) adaptor tops. Denso lower cushions. Set of 6.
	SC400	1050.60.11.D.8	ID1050x, for SC400 / 1UZ-FE V8 applications, 11mm (blue) adaptor tops. Denso lower cushions. Set of 8.
<b>Lotus</b>	Exige / Elise 05+	1050.30.01.60.11.4	ID1050x, for 05+ Exige & Elise / 2ZZ-GE applications. 11mm (blue) adapter tops. Denso lower cushions. Set of 4. Includes potted PNP wiring adaptors
<b>Mazda</b>	Miata 90-05	1050.11.02.60.11.4	ID1050x, for 90-05 Miata, 1.6L / 1.8L, 11mm (blue) adaptors, -204 lower cushions (remove lower o-ring retainer) Set of 4.
	Mazdaspeed Miata 94-05	1050.11.02.60.11.4	ID1050x, for 94-05 Mazdaspeed Miata / 1.8L Turbo, 11mm (blue) adaptors, -204 lower cushions (remove lower o-ring retainer) Set of 4.
	Miata 06-14	1050.60.14.14B.4	ID1050x, for 06-14 Miata, 14 mm (grey) adaptor top AND (silver) BOTTOM adaptor. Set of 4
	RX-7 79-84 (11mm)	1050.11.03.60.11.2	ID1050x, for 79-86 RX-7. 11mm (blue) adaptors. -204 / 14mm lower o-rings. Set of 2.
	RX-7 79-84 (14mm)	1050.11.06.60.14.2	ID1050x, for 79-86 RX-7. 14mm (purple) adaptors. -204 / 14mm lower o-rings. Set of 2.
	RX-7 87-88 (11mm)	1050.11.03.60.11.2	ID1050x, for 87-88 RX-7 (incl. Turbo II). 11mm (blue) adaptor top. -204 / 14mm lower o-rings. Set of 2.
	RX-7 87-88 (14mm)	1050.11.06.60.14.2	ID1050x, for 87-88 RX-7 (incl. Turbo II). 14mm (purple) adaptor top. -204 / 14mm lower o-rings. Set of 2.
	RX-7 89-92 (11mm)	1050.11.03.60.11.2	ID1050x, for 89-92 RX-7 (incl. Turbo II). 11mm (blue) adaptor top. -204 / 14mm lower o-rings. Set of 2.
	RX-7 89-92 (14mm)	1050.11.06.60.14.2	ID1050x, for 89-92 RX-7 (incl. Turbo II). 14mm (purple) adaptor top. -204 / 14mm lower o-rings. Set of 2.
	RX-7 93-95 (11mm)	1050.11.03.60.11.2	ID1050x, for 93-95 RX-7, Requires Top Feed Conversion. 11mm (blue) adaptors. -204 / 14mm lower o-rings. Set of 2.
	RX-7 93-95 (14mm)	1050.11.06.60.14.2	ID1050x, for 93-95 RX-7, Requires Top Feed Conversion. 14mm (purple) adaptors. -204 / 14mm lower o-rings. Set of 2.
RX-8 03-11	1050.60.11.D.2	ID1050x, for 03-11 RX-8, 11mm (blue) adaptors. Denso lower cushions. Set of 2. Secondaries Only. Two blue m8 washers	
<b>Mitsubishi</b>	Evo III - IX	1050.60.11.D.4	ID1050x, for Evo III-IX, 2.0L turbo. 11mm (blue) adaptor tops. Denso lower. Set of 4.
	Evo X	1050.48.14.14B.4	ID1050x, USCAR Connector, 48mm length, 14mm (black) BOTTOM adaptor. Set of 4.
	Eclipse GST/GSX	1050.60.11.D.4	ID1050x, for Eclipse GST/GSX, 2.0L turbo. 11mm (blue) adaptor tops. Denso lower. Set of 4.
	Galant VR4	1050.60.11.D.4	ID1050x, for Galant VR4, 2.0L turbo. 11mm (blue) adaptor tops. Denso lower. Set of 4.
	3000GT VR4	1050.60.11.D.6	ID1050x, for 3000GT VR4, 3.0L turbo. 11mm (blue) adaptor tops. Denso lower. Set of 6.
<b>Nissan</b>	300ZX TT (90-96) 11mm	1050.60.11.14.6	ID1050x, for 90-96 300ZX TT. 11mm (blue) adaptor tops. Set of 6. *Requires top feed conversion*
	300ZX TT (90-96) 14mm	1050.60.14.14.6	ID1050x, for 90-96 300ZX TT. 14mm (purple) adaptor tops. Set of 6. *Requires top feed conversion*
	350Z	1050.48.14.14.6	ID1050x, for 350z / VQ35. 14mm (grey) adaptor top. Set of 6.
	370Z	1050.48.14.R35.6	ID1050x, for 370z / VQ37. 14mm (grey) adaptor top. GTR lower spacer. Set of 6.
	GTR-R32, R33, R34 (11mm)	1050.60.11.D.6	ID1050x, for R32, R33, R34 / RB26. 11mm (blue) adaptor tops. Denso lower. Set of 6.
	GTR-R32, R33, R34 (14mm)	1050.60.14.D.6	ID1050x, for R32, R33, R34 / RB26. 14mm (purple) adaptor tops. Denso lower. Set of 6.
	GTR (R35)	1050.48.14.R35.6	ID1050x, for R35 / VR38. 14mm (grey) adaptor top. GTR lower spacer / 14mm bottom o-ring. Set of 6.

	GTR (R35) FOR V1 T1 Rails	1050.60.14.14-O.6	ID1050x, for R35 / VR38. 14mm (purple) adaptor top. 14mm bottom o-ring, machine o-ring retainer to 11mm. Set of 6. (No rails included)
	240SX-S13/S14/S15 (11mm)	1050.60.11.14.4	ID1050x, for SR20DET RWD. Top feed only. 11mm (blue) adaptor tops, 14mm lower o-ring. Set of 4.
	240SX-S13/S14/S15 (14mm)	1050.60.14.14.4	ID1050x, for SR20DET RWD. Top feed only. 14mm (purple) adaptor tops, 14mm lower o-ring. Set of 4.
	SR20DET FWD (11mm)	1050.60.11.14.4	ID1050x, for SR20DET RWD. Top feed only. 11mm (blue) adaptor tops, 14mm lower o-ring. Set of 4.
	SR20DET FWD (14mm)	1050.60.14.14.4	ID1050x, for SR20DET RWD. Top feed only. 14mm (purple) adaptor tops, 14mm lower o-ring. Set of 4.
	Patrol	1050.48.14.14.6	ID1050x, for Nissan Patrol. 14mm (grey) adaptor top. Set of 6.
	Sentra SE-R & Spec V 91-00	1050.48.14.14.4	ID1050x, for SE-R Spec V / QR25DE. 14mm (grey) adaptor top. Set of 4.
	Titan 04-15	1050.48.14.14.8	ID1050x, for 04-15Titan / VK56DE. 14mm (grey) adaptor top. Set of 8.
<b>Pontiac</b>	Firebird (93-97) LT1	1050.60.14.14.8	ID1050x, for 93-97 Firebird / LT1 applications. 14mm (purple) adaptors, set of 8.
	Firebird (98-02) LS1	1050.60.14.14.8	ID1050x, for 98-02 Firebird / LS1-LS6 applications. 14mm (purple) adaptors, set of 8
	Trans-Am (93-97) LT1	1050.60.14.14.8	ID1050x, for 93-97 Trans Am / LT1. 14mm (purple) adaptors, set of 8
	Trans-Am (98-02) LS1	1050.60.14.14.8	ID1050x, for 98-02 Trans Am / LS1-LS6 applications. 14mm (purple) adaptors, set of 8
	Turbo T/A (89 Anniv.)	1050.60.14.14.6	ID1050x, for 89 Turbo T/A applications. 14mm (purple) adaptors, set of 6
	GTO (2004) LS1	1050.60.14.14.8	ID1050x, for GTO 2004 / LS1 applications. 14mm (purple) adaptors, set of 8
	GTO (2005-2006) LS2	1050.48.14.15.8	ID1050x, for GTO 05-06 / LS2 applications. 14mm (grey) adaptor top. Orange lower o-ring. Set of 8.
	G8 GT	1050.34.14.15.8	ID1050x, for G8 GT / L76 applications. Standard (no adaptor). Orange lower o-ring. Set of 8.
	G8 GXP	1050.34.14.15.8	ID1050x, for G8 GXP / LS3 applications. Standard (no adaptor), Orange lower o-ring, set of 8
<b>Porsche</b>	996/997.1	1050.60.14.14.6	ID1050x, for 996/997.1 (Will not fit 997.2). 14mm (purple) adaptor top. 14mm bottom o-ring. Set of 6.
	996/997.1 TT	1050.48.14.14.6	ID1050x, for 996/997.1 TT (Will not fit 997.2 TT). 14mm (grey) adaptor top. Set of 6.
	993/911 84-98 (non turbo)	1050.60.14.14.6	ID1050x, for 84-98 993/911 (non turbo). 14mm (purple) adaptors. Set of 6.
<b>Saturn</b>	Ion Redline	1050.60.14.14.4	ID1050x, for Ion Redline/ 2.0L Supercharged applications, 14mm (purple) adaptors, set of 4.
	Sky (Non turbo)	1050.60.14.14.4	ID1050x, for Sky 2.4L Non-turbo applications, 14mm (purple) adaptors, set of 4
	Sky Redline (turbo)	N/A	Not applicable / Direct-Injection fuel system
<b>Scion</b>	tC (05-13) 2.4 & 2.5L	1050.17.01.60.11.4	ID1050x, for Scion tC (05-13). 11mm (blue) adaptor, Denso lower cushion. Set of 4.
			Injectors are supplied with potted PNP wiring adaptors. Normal electrical connectors will not fit due to clearance at the cylinder head.
	xB (01-15)	1050.60.11.D.4	ID1050, for xB (01-15). 11mm (blue) adaptor top. Denso lower cushion. Set of 4.
	FR-S (2013+)	1050.18.04.36.11.4	ID1050x, for Scion FR-S / FA20 2.0L applications. 11mm machined top, WRX-16B bottom adaptors. Set of 4.
<b>Subaru</b>	STi (04-06)	1050.18.01.48.14.4	ID1050x, for STi 04-06 / Turbo. Top-feed Conversion Kit. Dual Billet Fuel Rails. Set of 4 injectors. Two 2x8 lower o-rings.
	WRX (02-14) / STi (07-17)	1050.48.11.WRX.4	ID1050x, for WRX 02-11 & STi 07-11/ Turbo 2.0L & 2.5L. WRX-16B bottom adaptors. 11mm (red) adaptors
	Legacy GT / Forester XT (04-06)	1050.48.11.WRX.4	ID1050x, for Legacy GT & Forester XT / Turbo 2.0L & 2.5L. WRX-16B bottom adaptors. 11mm (red) adaptors
	BRZ (2013+)	1050.18.04.36.11.4	ID1050x, for Subaru BRZ / FA20 2.0L applications. 11mm machined top, WRX-16B bottom adaptors. Set of 4.
<b>Toyota</b>	Corolla GTS (83-87) 4AGE	1050.60.11.D.4	ID1050x, for Corolla GTS 83-87 / 4AGE applications. 11mm (blue) adaptor top. Denso lower cushion. Set of 4.
	Corolla CE, S, LE (03-04)	1050.60.11.D.4	ID850, for Corolla CE, S, and LE models. 11mm (blue) adaptor top. Denso lower cushion. Set of 4.
	Matrix (01-03)	1050.60.11.D.4	ID850, for Matrix XR and XRS. 11mm (blue) adaptor top. Denso lower cushion. Set of 4.
	MR-2 Turbo (90-96) 3S-GT	1050.60.11.14.4	ID1050x, for MR-2 Turbo 90-96 / 3S-GTE Top-feed applications. 11mm (blue) adaptor top. Set of 4.
	MR-2 Turbo (90-96) 3S-GT	1050.60.14.14.4	ID1050x, for MR-2 Turbo 90-96 / 3S-GTE Top-feed applications. 14mm (purple) adaptor top. Set of 4.
	MR-2 N/A (90-96) 5SFE	1050.60.11.D.4	ID1050x, for MR-2 Non-turbo 90-96 / 5SFE applications. 11mm (blue) adaptor top. Denso lower. Set of 4.
	MR-2 Spyder (00-05) 1ZZ	1050.60.11.D.4	ID1050x, for MR-2 Spyder 00-05 / 1ZZ-FE applications. 11mm (blue) adaptor top. Denso lower. Set of 4.
	Supra Turbo (87.5-92) 7M	1050.60.11.D.6	ID1050x, for Supra Turbo 87-92 / 7M-GTE applications. 11mm (blue) adaptor top. Denso lower cushion. Set of 6.
	Supra Turbo (93-98) 2JZ-G	1050.60.11.14.6	ID1050x, for Supra Turbo 93-98 / 2JZ-GTE applications. Currently top fed. 11mm (blue) top. Set of 6.
	Supra Turbo (93-98) 2JZ-G	1050.60.14.14.6	ID1050x, for Supra Turbo 93-98 / 2JZ-GTE applications. Currently top fed. 14mm (purple) top. Set of 6.

	Supra NA (93-98) 2JZ-GE	1050.60.11.D.6	ID1050x, for Supra Non-turbo 93-98 / 2JZ-GE applications. 11mm (blue) adaptor top. Denso lower. Set of 6.
	Celica All-Trac (89-99) 3S-	1050.60.11.14.4	ID1050x, for Celica All Trac 89-99 / 3S-GTE Top-feed applications. 11mm (blue) adaptor top. Set of 4.
	Celica All-Trac (89-99) 3S-	1050.60.14.14.4	ID1050x, for Celica All Trac 89-99 / 3S-GTE Top-feed applications. 14mm (purple) adaptor top. Set of 4.
	Celica GT (00-05) 1ZZ-FE	1050.60.11.D.4	ID1050x, for Celica GT 00-05 / 1ZZ-FE applications. 11mm (blue) adaptor top. Denso lower. Set of 4.
	Celica GTS (00-05) 2ZZ-GE	1050.30.01.60.11.4	ID1050x, for Celica GTS 00-05 / 2ZZ-GE applications. 11mm (blue) adapter top, Denso lower. Set of 4.
			Includes potted PNP wiring adaptors
	Landcruiser	1050.60.11.D.6	ID1050x, for Landcruiser. 11mm (blue) adaptor top. Denso lower. Set of 6.
	FJ Cruiser / 4Runner / Tur	1050.60.14.D.6	ID1050x, for FJ Cruiser / 4Runner / Tundra / 1GR V6 applications. 14mm (purple) adaptor top & Denso lower. Set of 6.
<b>Volkswagen</b>	VW 1.8T	1050.60.14.14.4	ID1050x, for Audi/VW 1.8t, 14mm (purple) top set of 4
	VW 2.0T	1050.60.14.14.4	ID1050x, for Audi/VW 2.0t, 14mm (purple) top set of 4
	VW VR6 (12v)	1050.60.14.14.6	ID1050x, for Audi/VW VR6 models (12 valve), 14mm (purple) adaptors. Set of 6
	VW VR6 (24v)	N/A	34mm length will not fit the 24 valve head, the bore in the head is too deep